



Art. 0103029N

BEYOND

Setup Instructions

Preparation:

- Compose all poles by connecting the single segments (fiberglass segments and metal segments)
- Close all door and window zips
- Choose the final position of the mounted tent

STEP 1

- Lay the flysheet on its final position on a level and clean ground
- Insert the fibreglass poles into the respective pole channels

STEP 2

- Consecutively connect the pole capsules to the pins fixed at the tent base (Ring-Pin System)
- Erect the tent by pulling simultaneously the 2 front guy lines
- Fix the tensioning metal poles onto the inside of the flysheet (using the dedicated pockets) and put them in tension. Now the tent is stabilized

STEP 3

- Tension the flysheet and fix it to the ground by using the supplied pegs

STEP 4

- Put the delivered guy lines in place for more stability

Always pay attention to tension tightly but without overdoing!

Connection to the vehicle through supplied accessories:

- Sluice pole with clamp
- Piping profile (already sewn on)

ATTENTION: Fold and stow your tent always in clean and dry condition!