Assemble instruction



Exploded View & Parts List



A.M6X12		X2 PC
B.M6		X2 PC
C.Ø6X16		X2 PCS